



Bulletin #120304 CFF portable fridge models Control unit configuration

CFF20/CFF35/CFF45 & CFF70DZ Compressor Controller Configuration

Background

The CFF fridge/freezers must be configured:

1. Whenever the Compressor Controller **OR** the Display PCB is replaced
2. If “1d” appears in the display (which means the compressor controller is not correctly configured).
3. If a user has inadvertently entered the “hidden menu” and made changes

Configuration process

1. Press **POWER** and **+** buttons together for 3s to access the hidden menu. Either 0, 1, 2, or 3 will show in display (most likely 3 which is the spare part default).



Correct configuration numbers for each model type are:

CFF20/CFF35/CFF45 Single Zone ID = 1

CFF70DZ Dual Zone ID = 3

2. Using **+** or **-** buttons, toggle until the correct ID is visible in display.
After ~4 seconds, the newly set ID value will blink 3 times before display returns to the normal interface.



Danny Newman
National Service Manager